



# **EW-Y Series Electronic Metering Pump Instruction Manual**

---

**W A L C H E M**

---

Five Boynton Road Hopping Brook Park Holliston, MA 01746 USA TEL 508-429-1110 FAX 508-429-7433

WEBSITE: [www.walchem.com](http://www.walchem.com)

## Notice

© 2007 WALCHEM Corporation  
Five Boynton Road, Holliston, MA 01746 USA  
tel (508) 429-1110 fax (508) 429-7433  
All Rights Reserved  
Printed in USA

## Proprietary Material

*The information and descriptions contained herein are the property of WALCHEM Corporation. Such information and descriptions may not be copied or reproduced by any means, or disseminated or distributed without the express prior written permission of WALCHEM Corporation.*

*This document is for information purposes only and is subject to change without notice.*

## Statement of Limited Warranty

*WALCHEM Corporation warrants equipment of its manufacture and bearing its identification to be free from defects in workmanship and material for a period of two years from date of delivery from the factory or authorized distributor under normal use and service and otherwise when such equipment is used in accordance with instructions furnished by WALCHEM Corporation and for the purposes disclosed in writing at the time purchased, if any. WALCHEM Corporation's liability under this warranty shall be limited to replacement or repair, F.O.B. Holliston, MA U.S.A. of any defective equipment or part which, having been returned to WALCHEM Corporation, transportation charges prepaid, has been inspected and determined by WALCHEM Corporation to be defective.*

*THIS WARRANTY IS IN LIEU OF ANY OTHER WARRANTY, EITHER EXPRESS OR IMPLIED, AS TO DESCRIPTION, QUALITY, MERCHANT-ABILITY, FITNESS FOR ANY PARTICULAR PURPOSE OR USE, OR ANY OTHER MATTER.*

*P/N E00130.B  
March 2007*

# TABLE OF CONTENTS

Thank you for choosing a Walchem E-Class metering pump. This instruction manual deals with the correct installation, operation, maintenance and troubleshooting procedures for the EW-Y model metering pumps. Please read through it carefully to ensure the optimum performance, safety and service of your pump.

<b>1.0</b>	<b>INTRODUCTION .....</b>	<b>1</b>
1.1	Safety and Caution Notes .....	1
1.2	Principle of Operation .....	1
1.3	Model Code .....	2
1.4	Specifications .....	3
1.5	Dimensions .....	4
<b>2.0</b>	<b>CONTROLLER SPECIFICATIONS .....</b>	<b>5</b>
2.1	Operation Modes .....	5
2.2	Display .....	5
2.3	Keypad .....	5
2.4	Control Functions .....	5
2.5	Inputs .....	5
2.6	Outputs .....	5
<b>3.0</b>	<b>INSTALLATION .....</b>	<b>6</b>
3.1	Unpacking .....	6
3.2	Location .....	6
3.3	Supply Tubing .....	7
3.4	Discharge Tubing .....	8
3.5	Installing Injection/BackPressure Valve .....	9
3.6	Electrical .....	9
<b>4.0</b>	<b>OPERATION .....</b>	<b>10</b>
4.1	Display and Keypad .....	10
4.2	Display Indicators .....	11
4.3	General Operation and Programming Menus .....	12
4.4	MultiFunction Valve Operation .....	17
4.5	Auto Air Vent Valve Operation .....	18
4.6	Priming .....	19
4.7	Calibration .....	19
4.8	AC Power Interruption .....	19
<b>5.0</b>	<b>EXTERNAL WIRING .....</b>	<b>20</b>
5.1	External Inputs & Outputs .....	20
<b>6.0</b>	<b>MAINTENANCE .....</b>	<b>23</b>
6.1	Diaphragm Replacement .....	23
6.2	Valve Replacement .....	23
6.3	Tubing .....	23
<b>7.0</b>	<b>EXPLODED VIEW &amp; PARTS GUIDE .....</b>	<b>24</b>
<b>8.0</b>	<b>TROUBLESHOOTING .....</b>	<b>31</b>
<b>9.0</b>	<b>SERVICE POLICY .....</b>	<b>32</b>

# 1.0 INTRODUCTION

## 1.1 Safety and Caution Notes



Always wear protective clothing, eye protection and gloves before working on or near a metering pump. Follow all recommendations of the supplier of the solution being pumped. Refer to the MSDS from the solution supplier for additional precautions.

Walchem E-Class metering pumps should be installed where ambient temperatures do not exceed 122°F (50°C) or do not fall below 32°F (0°C), or where pump or tubing are directly exposed to sunlight.



**WARNING Risk of electrical shock!** This pump is supplied with a grounding conductor and grounding-type attachment plug. To reduce the risk of electrical shock, be certain that it is connected only to a properly grounded, grounding type receptacle with ratings conforming to the data on the pump data plate. Prior to performing any maintenance on a pump, disconnect the pump from the electrical power source.



### Plumbing Precautions

All tubing must be securely attached to the fittings prior to starting the pump (see Section 2.3). Only use Walchem tubing with your pump. Tubing should be shielded to prevent possible injury in case of rupture or damage. UV resistant tubing should be used if the tubing is exposed to UV light. Always adhere to local plumbing codes and requirements. Be sure that the installation does not constitute a cross connection. Walchem is not responsible for improper installations. Prior to performing any maintenance on a pump, depressurize the discharge tubing.

If you are pumping downhill or into little or no system pressure, a back pressure/anti-siphon device must be installed to prevent over-pumping. Contact your Walchem distributor for additional information.




### Solution Compatibility

**CAUTION!** This pump has been evaluated for use with water only. The suitability of this pump for use with liquids other than water, such as acid and alkaline, is the responsibility of the user. For liquids other than water, select the best-suited liquid end material combination using a chemical compatibility chart.

## 1.2 Principle of Operation

The E-Class electronic metering pumps consist of a pump unit, a drive unit, and a control unit. The drive unit is an electromagnetic solenoid. When the solenoid coil is energized by the control unit the armature shaft moves forward due to the magnetic force of the solenoid. The shaft is attached to a PTFE faced diaphragm which is part of the pump unit. The diaphragm is forced into the pump head cavity decreasing volume and increasing pressure which forces liquid in the pump head out through the discharge check valves. When the solenoid coil is de-energized, a spring returns the armature to its starting position. This action pulls the diaphragm out of the head cavity increasing volume and decreasing pressure. Atmospheric pressure then pushes liquid from the supply tank through the suction check valves to refill the pump head.

### 1.3 Model Code



#### 1 Pump Series

**EW** IP 65 electronic metering pump with external pulse control or manual speed control (adjustable to 360 strokes per minute) and manually adjustable stroke length. (Turndown ratio 1800:1.)

#### 2 Capacity/Pressure Rating (See Section 1.4 for detailed chart.)

#### 3 Control Module

**Y** For use on all EW models, features programmable analog and digital inputs, a direct PosiFlow input and control, flow display w/easy calibration, selectable output and quick priming.

#### 4 Voltage

- 1** 115 VAC, 50/60 Hz
- 2** 230 VAC, 50/60 Hz

#### 5 Liquid End (See Section 1.4 for detailed chart.)

#### 6 Options

**C** High Compression Configuration: Supplied standard with Auto Air Vent Valve in place of manual air vent valve. Available for B10, B15, C15 and C20 sizes with -VC liquid ends only.

**M** Multifunction Valve is supplied in place of the manual air vent valve. Available for the EW and EK 10-20 sized pumps with VC, VE, VF, PC, and PE liquid ends. Not available with the AAVV feature.

## 1.4 Specifications

### Electrical

	50/60 Hz, single phase		
<b>EWB</b>	115 VAC±10%	0.8 Amp max.	20 watt avg.
	230 VAC±10%	0.4 Amp max.	20 watt avg.
<b>EWC</b>	115 VAC±10%	1.2 Amp max.	22 watt avg.
	230 VAC±10%	0.6 Amp max.	22 watt avg.

### Operating Conditions

Ambient temperature	32°F to 122°F (0°C to 50°C)
Relative humidity	To 85% (EW) / 95% (EK) non-condensing
Liquid temperature	32° to 104°F (0 to 40°C) for PVC based liquid ends 32° to 140°F (0 to 60°C) for PP, PVDF, SS based liquid ends Below 32°F (0°C), pump is limited to 70% of max. pressure. Liquid cannot freeze.

### Capacity/Pressure Rating

Size	Maximum Output Capacity		Output per Stroke (mL)		Maximum Pressure <sup>1</sup>		Connection Size (in) Tubing O.D
	(Gal/hr)	(mL/min)	Min.	Max.	PSI	MPa	
<b>B10</b>	0.6	38	0.03	0.11	150	1.0	3/8
<b>B15</b>	1.0	65	0.04	0.18	105	0.7	3/8
<b>B20</b>	1.8	115	0.07	0.32	60	0.4	3/8
<b>B30</b>	3.3	210	0.12	0.58	30	0.2	1/2
<b>C15</b>	1.3	80	0.05	0.22	150	1.0	3/8
<b>C20</b>	2.3	145	0.08	0.40	105	0.7	3/8
<b>C30</b>	4.3	270	0.15	0.75	50	0.35	1/2
<b>C35<sup>2</sup></b>	6.7	420	0.24	1.17	30	0.2	1/2

<sup>1</sup> Auto Air vent valve reduces maximum pressure approx. 35 PSI (0.2 MPa)

<sup>2</sup> Output of the EW/EKC35-TC/FC/SH is 6.3 GPH (400 ml/min)

### Adjustment Range

Stroke length adjustment range 20% to 100%  
Frequency adjustment range 0 to 360 strokes per minute


### Materials of Construction

Liquid End Code	Pump Head & Fittings	Diaphragm	Valve Balls	Valve Seat	Valve Seals	Gasket	Tubing
<b>PC</b>	GFRPP	PTFE (bonded to EPDM)	CE	FKM	FKM	PTFE	PE
<b>PE</b>	GFRPP		CE	EPDM	EPDM		
<b>VC</b>	PVC		CE	FKM	FKM		
<b>VE</b>	PVC		CE	EPDM	EPDM		
<b>VF</b>	PVC		PTFE	EPDM	EPDM		
<b>TC</b>	PVDF		CE	FKM	FKM		
<b>FC</b>	PVDF		CE	PCTFE	PTFE		
<b>SH</b>	SS		HC	HC	PTFE		1/4" NPTF

CE	Alumina ceramic	PE	Polyethylene
EPDM	Ethylene propylene diene monomer	PTFE	Polytetrafluoroethylene
FKM	Fluoroelastomer	PVC	Polyvinylchloride (translucent)
GFRPP	Glass fiber reinforced polypropylene	PVDF	Polyvinylidene fluoride
HC	Hastelloy C276	SS	316 stainless steel
PCTFE	Polychlorotrifluoroethylene		

## 1.5 Dimensions


*EW-10,15 and 20 Models with thermoplastic liquid end materials*



### Notes:

1. Addition of a Multifunction valve increases overall length by 0.37". Addition of an Auto Air Vent Valve increases overall length by 1.59"
2. Addition of a Multifunction Valve increases discharge height by 0.22". No change for the Auto Air Vent Valve.
3. Addition of a Multifunction Valve increases overall liquid end height by 1.16". No change for the Auto Air Vent Valve.
4. All dimensions in inches.

*EW-30 and 35 Models with thermoplastic liquid ends*



### Notes:

1. All dimensions in inches.

## 2.0 CONTROLLER SPECIFICATIONS

### 2.1 Operation Modes

Manual Operation:	MAN	1-360 SPM
External Operation:	DIV (dividing)	/ 1-9999
	MULT (multiplying)	X 1-9999
	ANA.R (analog, fixed)	4-20, 0-20, 20-4, 20-0 mA
	ANA. V (analog, variable)	2 points: 0.0-20.0mA range, 1-360 SPM range

### 2.2 Display

LCD:	14 segment, 5 digit	Shows capacity, alarm, SPM, etc.
LED:	ON: GREEN	Solid green with power, flashes off with stroke
	STOP: ORANGE/RED	Orange for PreSTOP, red for STOP activation
	OUT: RED	Red activated with OUT1 output

### 2.3 Keypad

Keypad:	5 pushbutton keys	START/STOP	UP
		EXT	DOWN
		DISP	

### 2.4 Control Functions

STOP / Pre-STOP	Pump continues to operate when Pre-STOP is activated, pump stops when STOP is activated.
PRIME	Pump runs at max stroke rate when the UP + DOWN keys are pressed
Keypad Lockout	Keypad can be locked out.
Calibration	Allows a flowrate display. Discharge capacity per stroke is calculated by operating the pump and entering the measured pumped volume.
Stroke counter	Roughly counts the total number of strokes the pump has done.
PosiFlow	Provides positive feed verification back to the pump. An output alarm is activated and the pump is stopped with no flow.
Memory	Provides ability to store up extra inputs to work off later. Default is set to OFF. OVER indicates pulses in memory. Max pulse storage is 75535 pulses.

### 2.5 Inputs

Digital	Non-powered contact closure or open collector.
Analog	DC 0-20mA (input resistance is 200Ω)
Level Sensor	(2 step capable) Non-powered contact closure or open collector
PosiFlow Sensor	Open collector (with 12VDC power output supplied)

### 2.6 Outputs

Output 1	Mech. Relay, Max.250V 2A	STOP, Pre-STOP, Count Up, PosiFlow STOP is default. One or more can be selected.
Output 2	Elec. Relay, Max. 24V 0.1A	STOP, Pre-STOP, synchronous with stroke, Count Up, PosiFlow, Pump Operation Synchronous with stroke is default. Only one output can be assigned to OUT2

**NOTE:** If OUT1 & OUT2 are both used, voltage is limited to AC/DC24V for each output.



## 3.0 INSTALLATION

### 3.1 Unpacking

Open the shipping carton and inspect contents for damage. If any items are missing or damaged contact your local distributor.



Pumps are pre-primed with water at the factory. If the application is not compatible with water, drain and dry before use. Be sure to remove caps from fittings before attaching tubing.

**CAUTION:** Head bolts may have loosened during storage or shipment. Be sure to check and tighten to 19 lb-in torque, if necessary.

### 3.2 Location

Choose a location for the pump which is clean, dry, close to an electrical outlet, and allows convenient access to stroke length control, frequency control, and tubing connections. Avoid areas where ambient temperature exceeds 122°F (50°C) or falls below 32°F (0°C), or where the pump or tubing would be exposed to direct sunlight.

This pump is cord connected and not intended for permanent mounting to a building structure. However, temporary mounting to stabilize the pump during operation may be necessary as long as tools are not required for the installation or removal of the pump.

Flooded suction (mounting the pump below the level of liquid in the supply tank) is strongly recommended, especially when pumping liquids that readily generate gas bubbles. Sodium hypochlorite and hydrogen peroxide are common examples of such liquids. (See Figure 1.)

If flooded suction mounting is not possible, a shelf adjacent to (but not directly above) the supply tank often works well. (See Figure 2.) The supply tank or cover can also be used if it has provisions for mounting a pump. (See Figure 3.) In any case, the total suction lift should not exceed 5 ft (1.5m).

Figure 1  
Flooded Suction  
Recommended for  
liquids that out-gas




Figure 2  
Shelf Mount





Figure 3  
Tank Mount






Figure 4  
Connecting Tubing

### 3.3 Supply Tubing

The supply tubing run should be as short as possible. For flooded suction mounting, install a shut-off valve with an appropriate tubing connector at the tank outlet. Cut a length of tubing from the coil supplied and install between the shut-off valve and the pump inlet fitting. For suction lift applications, slide on the ceramic weight, then install a foot valve on one end of suction tubing. Cut the tubing to a length such that the foot valve hangs vertically about 1 in (25mm) above the bottom of the tank. Avoid any loops in the tubing run that could form a vapor trap. Running the tubing through a length of pipe will help to keep tubing straight. Total vertical suction lift should be no more than 5ft. (1.5m). Reference Figure 4.

Attach tubing as shown in Figure 5. First slide the coupling nut, small end first, onto the tubing. Push the tubing over the valve housing tip *all the way to the valve housing shoulder*. (Tip: if the tubing is stiff from cold, dip the tubing end in hot tap water for a few minutes so it will slide on and flare out more easily. Push the coupling nut onto the threads. Apply some pressure on the coupling nut and tubing while tightening the nut, making sure the tubing has not backed off of the shoulder of the valve housing.



**WARNING:** *All fittings and coupling nuts should be tightened by hand only. If necessary, a small tool may be used to make it snug. DO NOT use excessive force or large wrenches.*

The coupling nut should not bottom out completely against the fitting. If this happens during connection, either the tubing has slid down the shoulder while tightening, or the tubing has been pinched. Remove the coupling nut, re-cut the tubing and re-connect.



**WARNING:** *If there is any leakage around the coupling nut and it appears to have been installed correctly, DO NOT TIGHTEN the coupling further! Release pressure in the line, disconnect tubing, re-cut and re-connect. Tightening of misinstalled tubing may cause the tubing to pop off under pressure.*




Figure 5  
Attaching the Tubing

### 3.4 Discharge Tubing

Cut a length of tubing long enough to go from the pump to the application (injection) point. Additional tubing can be ordered from your distributor. Avoid sharp turns or bends and hot surfaces. Routing tubing through rigid pipe such as PVC pipe is recommended for long runs and/or as protective shielding against corrosive chemicals. If applicable, install the injection valve in 1/2" NPT thread at the injection point (see section 2.5) and connect the discharge tubing to the injection valve.

Attach tubing as described in section 2.3 and as shown in Figures 5 and 6. Note: Some models have an air vent valve with two outlet connections. The connection marked 'OUT' is the discharge side to the application point. (Fig 6).

Attach a second length of tubing to the air vent side marked ('AIR') and route back to the chemical solution tank or drum. On the larger pumps (30 & 35 sizes), the air vent valve connections are not marked, however, the discharge side is the vertical (UP) connection and the air vent connection is on the side of the valve.




Figure 6  
Air Vent Valve Tubing

### 3.5 Installing Injection/BackPressure Valve


A fitting or tee with 1/2" NPTF threads and with sufficient depth will accept the injection valve assembly. If required, trim off an amount of the extension tip until it fits your fitting or tee. (Fig. 7.)

The position of the injection/back pressure valve can be at any orientation as long as the spring is retained in the valve. **DO NOT REMOVE THE SPRING.** Be sure to check and replace the spring as needed. Attach the tubing following the same instructions in section 2.3, connecting the supply tubing.

**CAUTION:** Some chemicals may have reactions as they are injected into the main flow. For example, sulfuric acid may react with water causing excess heat. If the chemical is heavier than water, mount the injection valve as close as possible to vertical coming into the bottom of the pipe. This will keep the injection nozzle facing up and keep the heavier chemistry from draining into the pipe and causing adverse reactions within the injection valve and pipe.

In addition to preventing backflow from pressurized lines, the injection valve acts somewhat as a back pressure valve when pumping into open atmosphere type applications. However, the back pressure by the injection valve is very low and can vary. The output of the metering pumps is rated at maximum back pressure and will increase as back pressure decreases dependent on the specific installation. Additionally, the valve does NOT act as an anti-siphon valve. If siphoning is a possibility, or if pumping downhill into open atmosphere (open tank), a Walchem MultiFunction valve or a separate back pressure/anti-siphon valve must be installed.

Note: Siphoning can also occur at the tip of the injection valve because of the high flow rate in the main pipe flowing past the small injection nozzle (venturi effect). In this case, an anti-siphon device must be installed to avoid over feeding or siphoning of chemistry.



### 3.6 Electrical




**WARNING Risk of electrical shock!** *This pump is supplied with a grounding conductor and grounding-type attachment plug. To reduce the risk of electrical shock, be certain that it is connected only to a properly grounded, grounding type receptacle.*

**CAUTION!** The electronics within the pump can be damaged by excessive surges in voltage. Do not install the pump near high-power electrical equipment that generate high surge voltages. Avoid branch circuits that also supply power to heavy or other equipment that could generate electrical interference. If necessary, install a surge suppression device (such as a varistor with a resistance greater than 2000A) or a noise reducing transformer at the pump's power connection.


## 4.0 OPERATION

### 4.1 Display and Keypad

The EW-Y Modules have a digital display, three LED indicators and five pushbutton keys to view the current settings and change the pump's operation and programming.




## 4.2 Display Indicators



- |    |                |                                                                                                                                                                  |
|----|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1  | <b>Display</b> | The operation conditions, menu choices, status, and selections are displayed                                                                                     |
| 2  | <b>MAN</b>     | Appears when the pump is operating in the MANUAL mode                                                                                                            |
| 3  | <b>DIV</b>     | Appears when the pump is operating in the EXTERNAL mode, set for DIVIDE                                                                                          |
| 4  | <b>MULT</b>    | Appears when the pump is operating in the EXTERNAL mode, set for MULTIPLY                                                                                        |
| 5  | <b>ANA.</b>    | Appears when the pump is operating in the EXTERNAL mode, set for an ANALOG input                                                                                 |
| 6  | <b>RV</b>      | Either R (four fixed choices) or V (two-point programmable ) appear next to ANA when set for ANALOG input                                                        |
| 7  | <b>P</b>       | Flashes on with each output of the PosiFlow sensor when it is wired directly into the pump                                                                       |
| 8  | <b>!</b>       | Appears after approximately 10 seconds of manually priming in the EXTERNAL mode and the pump then continues to prime without holding down the two keys           |
| 9  | <b>spm</b>     | Indicates that the output display is in strokes per minute                                                                                                       |
| 10 | <b>GPH</b>     | Appears when pump is set to display flowrate instead of SPM                                                                                                      |
| 11 | <b>mA</b>      | Appears when programming the ANALOG input points P1 and P 2 (see item #16)                                                                                       |
| 12 | <b>SET</b>     | Appears whenever a value can be programmed in the control unit                                                                                                   |
| 13 | <b>Disp</b>    | Appears anytime that the DISP key can be used to toggle between SPM and flowrate displays                                                                        |
| 14 | <b>Err</b>     | Shows that an error has occurred                                                                                                                                 |
| 15 | <b>LOCK</b>    | Appears when the keypad has been locked out                                                                                                                      |
| 16 | <b>P12</b>     | Either P1 or P 2 appears when programming the ANALOG input points (ANA. V)                                                                                       |
| 17 | <b>OVER</b>    | Appears when the analog signal is set to make the pump run faster than 360SPM or whenever there are strokes stored in the buffer memory (if B. MEM is set to ON) |

### 4.3 General Operation and Programming Menus

Upon powering up, the pump should be in the WAIT mode by default. In the WAIT mode, the pump is not running and displays the manually set stroke rate or flowrate. If the pump immediately begins to operate in either the MAN or EXT mode, pressing the STOP/START key will get back to the WAIT mode. From the WAIT mode, the pump can be run manually, configured and operated externally, outputs can be programmed, and calibration of the pump can be performed.



The up and down keys are used to change the SPM/flowrate setting of the pump for manual operation only. The DISPLAY key will switch the display between SPM and flowrate if a calibration has been performed (toggling between SPM and flowrate is available anytime the “DISP” indicator is illuminated). “NoCAL” will show if a calibration has never been performed. The flowrate will be blinking if the pump is out of calibration because the stroke length knob has been turned and another calibration must be performed to view the output flowrate.

#### A. MANUAL Operation


From the WAIT mode, pressing the start/stop key will begin manual operation of the pump and the “MAN” indicator will illuminate. The pump will begin pumping and display the set SPM/flowrate. Using the up and down keys will increase or decrease the SPM/flowrate respectively. Pressing the start/stop key again will return to the WAIT mode and stop the pump.

## B. USER Program Menu

From the WAIT mode, pressing the EXT key for 3-5 seconds will enter the USER Program menu (see flowchart on next page). The up and down keys will scroll through the seven menu options and the stop/start key will exit back to the wait mode. The DISP key and the UP and DOWN keys will navigate through each of the menu options.

- EXT:** Sets the type and style of external signal to control the pump. The default, ANA.V, selects analog control allowing the signal to be set with two points. ANA.R selects analog control from one of four pre-set slopes. MULT or DIV set the external input to accept a digital input with the pump output as a multiple or fraction of the incoming signals. (Specific variables for the selection are configured in EXT Operation – see Section 3.3C)
- OUT1:** Sets the parameter(s) that will trigger output 1. One, all, or any combination of the options can trigger output 1 if they are set to “-Y”. If the PosiFlow input is used, output 1 is triggered during a no-flow scenario in addition to user-selected parameters for output 1. **CAUTION:** *If more than one parameter is set for output 1 and OUT1 turns on, there is no way to remotely identify which parameter is causing the signal.*
- STOP:** STOP is the default setting for OUT1. OUT1 will activate when a stop input signal is received.  
Pre-STOP:OUT1 will activate when a pre-stop input signal is received.
- Count Up:** Used in the MULT mode for batching, warning of input signal failure, etc. OUT1 will activate once the number of pump strokes in memory have been worked off (when counting down strokes reaches 0). e.g. If setup mode is MULT and setting is x250, then after an input contact, OUT1 will shut off, the display will show 250 and begin counting down with each pump stroke, and once it hits 0, OUT1 will activate again until another input signal is sent.
- PosiFlow Alarm:** Automatically is assigned to output 1 when one of the modes is selected under the FL.CHK menu. OUT1 activates when there is no signal from the PosiFlow sensor.
- OUT2:** Sets the parameter that will trigger output 2. For output 2, only one of the six selections can be chosen. Default output for OUT2 is set for SPM. See descriptions in OUT1 for common options.
- SPM:** SPM is the default setting for OUT2. OUT2 will temporarily activate with each pump stroke. This can be used to drive another pump via a pulse input.
- P.RUN:** OUT2 will activate continuously while the pump is in MAN operation and pumping or running in EXT mode (even if not pumping).
- FL.CHK:** Sets the mode or shuts off the input from a PosiFlow sensor. During no-flow scenarios, OUT1 is activated and the pump will stop based on the mode selected. Default is set to OFF.
- MODE A:** After the user-defined number of pulses is missed, the pump stops, OUT1 activates and a “FLOW” error is indicated. OUT2 activates if programmed for FL.CHK.
- MODE b:** After the user-defined number of pulses is missed, OUT1 activates (OUT2 if programmed for FL.CHK) and the pump continues to run for another 360 strokes. If no PosiFlow signal is received, the pump stops and a “FLOW” error is indicated.
- MODE C:** After the user-defined number of pulses is missed, the pump continues to run for another 360 strokes. If no PosiFlow signal is received, the pump stops, OUT1 activates (OUT2 if programmed for FL.CHK) and a “FLOW” error is indicated.
- ANTI.C:** Sets the type of digital input signal expected. MECH is used for a mechanical type reed switch/contact closure. 5, 20 or 50 msec. minimum required closure times (to register a contact) can be selected to help eliminate switch bounce. ELEC is used for a high-frequency semiconductor type switch (Hall Effect sensor) and is triggered on the fall of the closure. 1, 2 or 4 msec. can be selected as the time between falls. Default setting is MECH at 5 msec.
- b.MEM:** Buffer memory can be switched on or off. Default is set on and the pump will retain incoming pulses and work them off if they come in too fast.
- T.C.:** Used for viewing the number of total strokes that the pump has done. The number shown is rounded down and displayed in thousands (x1000). Pressing the UP and DOWN keys together will reset the Total Counter.





### C. EXTERNAL Operation and Programming

From the WAIT mode, pressing the EXT key will begin pump operation in the external mode. (The default external mode is set for a programmable analog signal (ANA.V), but can be changed in the EXT section of the USER Program Menu.) From the EXT Operation mode, pressing the EXT key again will allow setting of the individual parameters. While setting the parameters, "SET" will be appear in the display.


#### External Mode of Operation:

- ANA.V: Pressing the EXT key continuously will cycle through setting the two set points, P1 and P2 ("SET" becomes illuminated). The up and down keys change the analog or SPM/flowrate settings within each set point. Any straight-line slope can be created within a range of 0-360 SPM and 0-20mA.
- ANA.R: Pressing the EXT key moves into the "SET" mode. The up and down keys cycle through the four pre-set analog selections: 4-20, 20-0, 0-20, & 20-4 (0SPM always correlates to the first value and 360SPM always is the 2<sup>nd</sup> value). Press EXT again to go to back to running in external operation.
- MULT: Pressing the EXT key moves into the "SET" mode to multiply the output of a digital input. The up and down keys change the pump stroke multiple for every input pulse. Pressing EXT again will to back to external operation. Note: For external operation with 1:1 input, pump should be set to MULT mode with a \*1 setting.
- DIV: Pressing the EXT key moves into the "SET" mode to divide the number of digital inputs. The up and down keys change the number of input pulses that will correlate to each pump stroke. Press EXT again to go to back to running in external operation.

### D. CALIBRATION Menu

The built in calibration menu of the EW-Y module facilitates easy calibration and flowrate display. Calibration of an EW-Y metering pump is best performed if the pump is installed in the actual application under normal conditions. The pumps should be primed, free from air in the suction/discharge lines and pumping chemical from a calibration column or scale.

**NOTE:** Before calibration, select the optimum stroke length setting so that future



*adjustment can be done with rate only. Changing the stroke length after calibration creates an incorrect flowrate reading and an error message.*

From the WAIT mode, pressing and holding the display key for 3-5 seconds will enter the calibration menu. **NOTE:** *Once in the calibration mode, the steps to perform a calibration must be made.* However, if calibration mode is accidentally entered, run the pump a couple of strokes and enter 0.0 gallons. This will exit through and an accurate calibration can be done again later.

### E. Priming Function

The pump can be temporarily operated at full speed (360SPM) in the WAIT mode and during EXT or MAN operation by pressing the UP and DOWN keys together. “PRIME” will appear on the display. If either or both keys are released, the pump returns to the previous mode of operation. Holding the UP and DOWN keys for 10 seconds sets the pump for continuous “PRIME” even when the keys are released and a “!” appears on the display. Pressing either of the UP or DOWN keys will exit out of continuous priming mode.

### F. Keypad lockout Function


The keypad can be temporarily locked out so that none of the keys will respond. This can be used to limit accidental changing of pump parameters, operation mode, recalibration, or tampering. Pressing and holding the START/STOP key for 5+ seconds will lock out the keypad. “LOCK” will appear along the bottom of the display. Pressing the START/STOP key again for 5+ seconds will unlock the keypad.

### G. Programming Reset


The programming done in the USER Program menu can be easily reset to factory defaults by holding down the EXT key while applying power to the pump (plugging it in). “LOAD.d” will temporarily appear on the display indicating that the programming has been reset. Pump calibration will not be lost during this step. Resetting the programming is helpful with troubleshooting and if settings do not appear to be functioning properly.

### H. Error Indicators

There are four basic error messages that are displayed during operation and programming. The display will blink these messages to indicate the following:



“DISCN” will flash in the display in ANA. R (fixed analog) mode when the settings are 4-20 or 20-4mA, but the input signal falls below 4mA. It signifies that there is a disconnection in the analog signal.



“FLOW” flashes in the display when the PosiFlow stops sending signals. Pressing the Start/Stop key will reset this error. Re-prime the pump and begin normal operation.



“NoCAL” flashes in the display whenever the DISP key is pressed to view flowrate, but a calibration has not yet been performed. Pressing the DISP key again will go back to the previous mode. From the WAIT mode, a calibration can be performed.



A flashing flowrate in the display is an indication that the stroke length knob has been adjusted since calibration, rendering the visible flowrate inaccurate. Another calibration is required to reset the flowrate. This can be done in the CAL Menu from the WAIT mode.

#### 4.4 MultiFunction Valve Operation

The MultiFunction Valve is optional on select E-Class pumps and replaces the standard Manual Air Vent Valve when ordered. It integrates the air venting/bleeding functions with a back pressure and anti-siphon valve.

##### Air Vent / Bleed Function


1. Open the air vent by turning the air vent adjustment knob counter-clockwise one to one and a half turns.
2. Operate the pump until all of the air is purged and only liquid is discharged from the air vent drain.
3. Turn the air vent adjustment knob clockwise until it bottoms out and will not turn further.


##### Back Pressure / Anti-Siphon Valve

1. A spring-loaded diaphragm automatically adds 30PSI of back pressure to the discharge side of the pump when the air vent adjustment knob is closed.
2. If back pressure is not observed, the pressure release knob may be in the release position (the knob is resting in its 'up' location). If this is the case, turn the knob clockwise until it 'clicks' down (approximately  $\frac{1}{4}$  turn).
3. The diaphragm prevents siphoning of chemical through the pump.

##### Pressure Release

1. Stop the pump operation.
2. Turn the pressure release knob clockwise until it 'clicks' into the release or 'up' location (approximately  $\frac{1}{4}$  turn). If the knob is turned too far, it will 'click' again return to the back pressure or 'down' position. If this happens, keep turning the knob clockwise until it 'clicks' one time in the release ('up') position.
3. Turn the air vent adjustment knob counter-clockwise one or one and a half turns to release the pressure in the discharge tubing/piping through the air vent drain. The air vent drain should always be plumbed back to the supply tank or to safe disposal. Do not submerge the air vent drain tubing under chemical in the supply tank.


 **CAUTION:** Confirm that liquid is discharged from the air vent drain. If the liquid is not discharged, the pressure may not be released. If this is the case, repeat the Pressure Release procedure.



#### 4.5 Auto Air Vent Valve Operation

The Auto Air Vent Valve is an option on select EW and EK pumps and replaces the standard Manual Air Vent Valve when ordered. It is used primarily in applications where gassing is a problem and pumps can lose prime.

Unlike the Manual Air Vent Valve, the Auto Air Vent Valve constantly bleeds a controlled amount of volume out of the “Air” vent. Therefore, the “Air” vent should *always* be plumbed back to the source tank. During priming, the access knob does not have to be loosened as with a manual air vent valve as pressure is relieved through the vent. The Top Valve Guide assembly uses a bottom seat to ensure that air is not introduced into the discharge media and utilizes a precisely machined top seat that allows air to be quickly purged but limits the amount of liquid returned to the tank. A sleeve valve is used to maintain backpressure within the pump head, which helps speed the purging of air.



## 4.6 Priming

Install the pump as described in Section 2.0. With the pump turned on, set stroke length at 100% and frequency to 360 SPM. If the pump is equipped with an air vent valve, open the knob 1/2 turn. Liquid should move up through the suction tubing and into the pump head. When liquid starts running through the vent side tubing, close the air vent knob and continue with output adjustment described below. If the pump has no air vent valve, disconnect the discharge tubing from the injection valve. When liquid enters the discharge tubing at the pump head, stop the pump. Then reconnect the discharge tubing to the injection valve.

If the pump does not self prime, remove the check valve housing on discharge & suction sides to make sure valve cartridges and gaskets are in correct positions (see section 4.2 for correct orientation).

**Note:** Pumps with FC liquid ends may need assistance if dry priming due to the hard valve seat material.

## 4.7 Calibration




Figure 8 Calibration

If exact output calibration is required, first prime and adjust the pump as above. Then connect a calibration column to the suction side of the pump. Turn the pump on for one minute and read the amount of liquid pumped from the column. Adjust the frequency up or down as necessary and check the output again. When the desired output is reached, disconnect the calibration column and reconnect the suction tubing. (See Figure 8.) Calibration must be performed with actual application equivalent back pressure for accurate results. Published flow rates are based on maximum pressures. Lower pressures may result in slightly higher flow rates.

## 4.8 AC Power Interruption

If AC power is interrupted, the pump will power up as shown below:

State preceding power OFF	State following power ON
WAIT	WAIT
Run Manual	Run Manual
Run external	Run external

## 5.0 EXTERNAL WIRING


### 5.1 External Inputs & Outputs

The EW-Y control module is capable of being controlled by an external digital pulse input or an analog control signal, as well as being controlled by an external stop/start signal. Additionally, the EW-Y pumps have two output relays that can be programmed to activate based on a number of options, alarms, or errors.

#### A. Connections


Three circular mini-DIN female connectors are used to make the input connections and one square mini-DIN connector is used for the two outputs. The figure below represents the input connections on the EW-Y housing and identifies each input of the connectors:

Connector 1 is a 5-PIN standard-key connector (P/N E90495) – included with pump.  
 Connector 2 is a 4-PIN reverse-key connector (P/N E90494) – sold separately.  
 Connector 3 is a 5-PIN reverse-key connector (P/N E90496) – sold separately.  
 Connector 4 is the square mini-DIN connector (P/N E90497) – sold separately.




#### B. External Digital Control

An external pulse input is used when the pump is setup for the MULT or DIV setting in the EXT Operation mode. The control signal can be a contact closure type switch (reed) with a max load of 1mA or a solid-state device. If a solid-state device is used, the external circuit should be capable of switching 5VDC at 1.8mA.



To connect the pulse input from an external device, wire PINs 2 and 5 from the contact closure. If using a solid-state switching device, wire the connector ensuring that PIN 2 is positive (+) and PIN 5 is Common (-). PIN 4 can be used to supply 12VDC (10mA max) to such a device (Hall Effect Sensor, for example).


### C. External Analog Control



An external analog input is used with a 0-20mA current signal and the pump is setup for either ANA.R (fixed) or ANA.V (programmable) in the EXT Operation mode. The impedance across the analog signal is 200 Ohms, so ensure that the powered current signal is 5VDC at a minimum. Maximum recommended current voltage is 25VDC.

To connect the analog input from an external device or loop, wire PINs 1 and 5 as shown on the left. Wire the connector ensuring that PIN 1 is positive (+) and PIN 5 is Common (-).

### D. STOP and Pre-STOP Inputs




The EW-Y pumps have two stop inputs. The Pre-Stop is an external input that changes the STOP LED to orange to signal a “LOW” condition. This input does not provide any control of the pump, however, either of the outputs can be set to activate with the Pre-STOP input signal.

An external STOP input signal not only turns the STOP LED to red, but also controls the pump. With AC power applied to the pump continuously, pump operation can be stopped by completing the circuit between PIN 1 and PIN 4 in Connector 2 (Normally Open). Both the Pre-STOP and STOP input signals can be a contact closure type switch (reed) with a max load of 1mA or a solid-state device. If a solid-state device is used, the external circuit should be capable of switching 5VDC at 1.8mA.

To connect the Pre-STOP input from an external device, wire PINs 2 and 4 from the contact closure. If using a solid state switching device, wire the connector ensuring that PIN 2 is positive (+) and PIN 4 is Common (-).

To connect the STOP input from an external device, wire PINs 1 and 4 from the contact closure. If using a solid-state switching device, wire the connector ensuring that PIN 1 is positive (+) and PIN 4 is Common (-).

### E. PosiFlow Inputs




Connector 3 is used to connect the PosiFlow sensor directly into the EW-Y control module. Using the PosiFlow sensor, the control module can verify if the solenoid output is directly being transferred into pumping liquid. If these two do not match, OUT1 will be activated and the pump will eventually stop operation. Programming the FL.CHK option in the USER mode must be done to turn on the PosiFlow input (see section 3.3B).

From the PosiFlow sensor, three wires are to be installed – red, white and black. PIN 2 is used for the red wire to supply the 12VDC (10mA) output. PIN 1 is for the white signal wire input and PIN 5 is for common – the black PosiFlow wire.



## F. Output Relays

The EW-Y pumps have two output relays in the square Connector 4. OUT 1 is a mechanical relay capable of switching 250VAC 2A when it is the only output being used. OUT 2 is a Photo MOS relay capable of switching AC/DC 24V 0.1A. If both relays are used, the max voltage for either relay is reduced to AC/DC 24V 0.1A. Without any external input voltage, both output relays will act as non-powered contact closures.



OUT 1 can be set to close with any one or combination of the following: a Pre-STOP input signal, a STOP input signal (factory default setting), Count Up (used in MULT mode), and is always activated when the PosiFlow is set on and it is not sensing flow pulses.

OUT 2 can be set to close with any one of the following: a Pre-STOP input signal, a STOP input signal, SPM (factory default setting), Count Up (used in MULT mode), PosiFlow Alarm, and Pump Run.

The figure to the left shows a schematic of the PINS configured to switch the relays. Wire the mating connector accordingly.

## 6.0 MAINTENANCE


**CAUTION:** Before working on the pump, disconnect the power cord, depressurize the discharge tubing and drain or flush any residual liquid from the pump head and valves. Always wear protective gear when working around chemicals.

### 6.1 Diaphragm Replacement

Disconnect AC power to the pump and disconnect the suction tubing, discharge tubing, and air vent tubing. Remove the four head bolts with a 4mm or 5mm hex wrench. Turn the stroke length knob fully counter-clockwise. Unscrew the diaphragm and remove its retainer (small disk behind the diaphragm). **CAUTION:** *There may be small brass spacers between the retainer and the armature shaft. These spacers need to be reused when replacing the diaphragm.* Install the new retainer and diaphragm on the shaft. Turn the diaphragm clockwise until it bottoms on the shaft. Replace the pump head and tighten the head bolts to a torque of 19 lb-in (2.16 N-m).

### 6.2 Valve Replacement

Remove the suction and discharge tubing making sure discharge side has been depressurized. Remove the suction fitting, two valve cartridges, o-ring and gasket(s). Install the new o-ring, gasket(s) and valve cartridges. Be sure both valve seats are in the same orientation. Refer to Figure below. Tighten the suction fitting. Similarly remove and replace the discharge valve cartridges, o-ring and gasket(s). For a more detailed drawing, refer to the Section 7.0.




### 6.3 Tubing

Check ends of tubing for splits, cracks, or thin spots. Examine the full length of tubing for damage due to chafing, abrasion, stress cracks, excessive temperature or exposure to ultraviolet light (direct sunlight or mercury vapor lamps). If any signs of deterioration exist, replace the entire length of tubing. It is a good idea to replace discharge tubing on a regular preventive maintenance schedule every 12 months.

# 7.0 EXPLODED VIEW & PARTS GUIDE

## PVC/GFRPP Liquid End Exploded View #1 For EW pump model sizes 10, 15, and 20




## PVC/GFRPP Liquid End Exploded View #1

### Components

Item	Part No	Description	Qty	Size	Liquid End Material	
1	EH1339	Head, Pump, EW/EK10, PVC	1	10	VC, VE, VF	
	EH1344	Head, Pump, EW/EK10, GFRPP	1	10	PC, PE	
	EH0557	Head, Pump, EW/EK/EZ15, PVC	1	15	VC, VE, VF	
	EH0582	Head, Pump, EW/EK/EZ15, GFRPP	1	15	PC, PE	
	EH0564	Head, Pump, EW/EK/EZ20, PVC	1	20	VC, VE, VF	
	EH0584	Head, Pump, EW/EK/EZ20, GFRPP	1	20	PC, PE	
3	EH0400	Housing, Valve, 3/8 PVC	1	10, 15, 20	VC, VE, VF	
	EH0418	Housing, Valve, 3/8 GFRPP	1	10, 15, 20	PC, PE	
4	EH0401	Nut, Coupling, 3/8 PVC	3	10, 15, 20	VC, VE, VF	
	EH0419	Nut, Coupling, 3/8 GFRPP	3	10, 15, 20	PC, PE	
5	EH0294	Fitting, Air Vent, PVC	1	10, 15, 20	VC, VE, VF	
	EH0315	Fitting, Air Vent, GFRPP	1	10, 15, 20	PC, PE	
6	EH0295	Nut, Lock, Air Vent, PVC	1	10, 15, 20	VC, VE, VF	
	EH0316	Nut, Lock, Air Vent, GFRPP	1	10, 15, 20	PC, PE	
*	8	E90064	Diaphragm and Retainer, EW/EK/EZ10	1	10	all
	E90065	Diaphragm and Retainer, EW/EK/EZ15	1	15	all	
	E90066	Diaphragm and Retainer, EW/EK/EZ20	1	20	all	
10	EH0402	Body, Manual Air Vent, PVC	1	10, 15, 20	VC, VE, VF	
	EH0420	Body, Manual Air Vent, GFRPP	1	10, 15, 20	PC, PE	
	EH0861	Body, Auto Air Vent, PVC	1	10, 15, 20	VCA, VCC	
	EH1406	Body, Multifunction Valve, PVC	1	10, 15, 20	VC, VEM, VFM	
	EH1407	Body, Multifunction Valve, GFRPP	1	10, 15, 20	PCM, PEM	
*	11	EH0060	Guide, Valve, .188 PVC	4	10	VC, VE, VF
	EH0318	Guide, Valve, .188 GFRPP	4	10	PC, PE	
	EH0068	Guide, Valve, .250 PVC	4	15, 20	VC, VE, VF	
	EH0325	Guide, Valve, .250 GFRPP	4	15, 20	PC, PE	
*	12	EH0061	Seat, Valve, .188 FKM	4 (5)	10	VC, PC (VCC)
	EH0048	Seat, Valve, .188 EPDM	4	10	VE, PE, VF	
	EH0069	Seat, Valve, .250 FKM	4	15, 20	VC, PC	
	EH0071	Seat, Valve, .250 EPDM	4	15, 20	VE, PE, VF	
*	13	EH0025	Ball, Valve, .188 CE	4 (5)	10	VC, VE, PC, PE, (VCC)
	EH0084	Ball, Valve, .250 CE	4	15, 20	VC, VE, PC, PE	
	E00063	Ball, Valve 0.188 PTFE	4	10	VF	
	E00064	Ball, Valve 0.250 PTFE	4	15, 20	VF	
*	14	EH0026	Gasket, Valve, .188 & .250 PTFE	2	10, 15, 20	VC, VE, VF
	EH0580	Gasket, Valve, .188 & .250 PTFE	2	10, 15, 20	PC, PE	
*	17	EH0027	O-Ring, S14 FKM	2	10, 15, 20	VC, PC
	EH0050	O-Ring, S14 EPDM	2	10, 15, 20	VE, PE, VF	
19	EH1630	Bolt, M4 x 30 SS Hex Socket	4	10, 15, 20	all	
21	E90374	Multifunction Valve Top Asm	1	10, 15, 20	all xxM ends	
22	EH1410	Screw, M4 x 10, SS304, PP	4	10, 15, 20	all xxM ends	
23	EH0299	Knob, Manual Air Vent Valve, PVC	1	10, 15, 20	VC, VE, VF	
	EH0321	Knob, Manual Air Vent Valve, GFRPP	1	10, 15, 20	PC, PE	
*	25	EH0300	O-Ring, P4 FKM	1	10, 15, 20	VC, PC
	EH0301	O-Ring, P4 EPDM	1	10, 15, 20	VE, PE, VF	
*	26	EH0302	O-Ring, P10A FKM	1	10, 15, 20	VC, PC
	EH0303	O-Ring, P10A EPDM	1	10, 15, 20	VE, PE, VF	
*	27	EH0304	O-Ring, P7 FKM	1	10, 15, 20	VC, PC
	EH0305	O-Ring, P7 EPDM	1	10, 15, 20	VE, PE, VF	
28	EH0864	Fitting, Adapter, AAVV, PVC	1	10, 15, 20	VCC	
29	EH0867	Fitting, AAVV, PVC	1	10, 15, 20	VCC	
30	EH0774	Knob, AAVV, PVC	1	10, 15, 20	VCC	
31	EH0862	Guide, Valve, AAVV, Titanium	1	10, 15, 20	VCC	
32	EH0775	Spacer, AAVV, PVC	1	10, 15, 20	VCC	
*	33	EH0865	Tube, Valve, AAVV, FKM	1	10, 15, 20	VCC
*	34	EH0776	O-Ring, S12, FKM	1	10, 15, 20	VCC
35	EH0866	Gasket, AAVV, FKM	1	10, 15, 20	VCC	
ZZ	-----	Brass Spacers			Drive specific/Reuse when replacing diaphragm	

\* Included in spare parts kit

**PVC/GFRPP Liquid End Exploded View #2**  
 For EW pump model sizes 30 and 35




## PVC/GFRPP Liquid End Exploded View #2

### Components

Item	Part No	Description	Qty	Size	Liquid End Material
1	EH1345	Head, Pump, EW/EK30, GFRPP	1	30	PC, PE
	EH1340	Head, Pump, EW/EK30, PVC	1	30	VC, VE, VF
	EH1346	Head, Pump, EW/EK35, GFRPP	1	35	PC, PE
	EH1341	Head, Pump, EW/EK35, PVC	1	35	VC, VE, VF
3	EH0405	Housing, Valve, 1/2 PVC	1	30, 35	VC, VE, VF
	EH0421	Housing, Valve, 1/2 GFRPP	1	30, 35	PC, PE
4	EH0406	Nut Coupling, 1/2 PVC	3	30, 35	VC, VE, VF
	EH0422	Nut, Coupling, 1/2 GFRPP	3	30, 35	PC, PE
5	EH1078	Fitting, Air Vent, PVC	1	30, 35	VC, VE, VF
	EH1088	Fitting, Air Vent, GFRPP	1	30, 35	PC, PE
6	EH1077	Nut, Lock, Air Vent, PVC	1	30, 35	VC, VE, VF
	EH1087	Nut, Lock, Air Vent, GFRPP	1	30, 35	PC, PE
*	8	E90067 Diaphragm and retainer, EW/EK/EZ30	1	30	all
	E90490	Diaphragm & Retainer, EW/EK/EZ35	1	35	all
10	EH1101	Body, Manual Air Vent, PVC	1	30, 35	VC, VE, VF
	EH1099	Body, Manual Air Vent, GFRPP	1	30, 35	PC, PE
*	11	EH0118 Guide, Valve, 0.375 PVC	4	30, 35	VC, VE, VF
	EH0332	Guide, Valve, 0.375 GFRPP	4	30, 35	PC, PE
*	12	EH0119 Seat, Valve, 0.375 FKM	4	30, 35	VC, PC
	EH0125	Seat, Valve, 0.375 EPDM	4	30, 35	VE, PE, VF
*	13	EH0120 Ball, Valve, 0.375 CE	4	30, 35	VC, VE, PC, PE
	E00062	Ball, Valve, 0.375 PTFE	4	30, 35	VF
*	14	EH0121 Gasket, Valve, 0.375 PTFE	2	30, 35	VC, VE, PC, PE, VF
*	15	EH1080 O-Ring, P-3, FKM	1	30, 35	VC, PC
	EH1083	O-Ring, P-3, EPDM	1	30, 35	VE, PE, VF
*	16	EH0029 O-Ring, P-6, FKM	1	30, 35	VC, PC
	EH0052	O-Ring, P-6, EPDM	1	30, 35	VE, PE, VF
*	17	EH0122 O-Ring, P16 FKM	2	30, 35	VC, PC
	EH0127	O-Ring, P16 EPDM	2	30, 35	VE, PE, VF
*	18	EH0027 O-Ring, S-14 FKM	1	30, 35	VC, PC
	EH0050	O-Ring, S-14 EPDM	1	30, 35	VE, PE, VF
19	EH0403	Bolt, M4 x 33 SS Hex Socket	4	30	all
	EH1347	Bolt, M5 x 35 SS Hex Socket	4	35	all
23	EH1079	Knob, Manual Air Vent, PVC	1	30, 35	VC, VE, VF
	EH1089	Knob, Manual Air Vent, GFRPP	1	30, 35	PC, PE
*	27	EH1082 O-Ring, P-11 FKM	1	30, 35	VC, PC
	EH1084	O-Ring, P-11, EPDM	1	30, 35	VE, PE, VF
ZZ	-----	Brass Spacers			Drive specific/Reuse when replacing diaphragm
*	Included in spare parts kit				

### PVDF Liquid End Exploded View #3 For all PVDF EW Pump Models



### PVDF Liquid End Exploded View #3

#### Components

Item	Part No	Description	Qty	Size	Liquid End Material
1	EH0608	Head, Pump, EW/EK/EZ10, PVDF	1	10	FC, TC
	EH0609	Head, Pump, EW/EK/EZ15, PVDF	1	15	FC, TC
	EH0610	Head, Pump, EW/EK/EZ20, PVDF	1	20	FC, TC
	EH1538	Head, Pump, EW/EK30, PVDF	1	30	FC, TC
	EH1518	Head, Pump, EW/EK35, PVDF	1	35	FC, TC
3	EH0425	Housing, Valve, 3/8 PVDF	2 / 1	10, 15, 20	FC / TC
	EH0427	Housing, Valve, 1/2 PVDF	2 / 1	30, 35	FC / TC
4	EH0836	Nut, Coupling, 3/8 PVDF	2 / 3	10, 15, 20	FC / TC
	EH0837	Nut, Coupling, 1/2 PVDF	2 / 3	30, 35	FC / TC
5	EH1051	Fitting, Air Vent, PVDF	1	10, 15, 20	TC
	EH1093	Fitting, Air Vent, PVDF	1	30, 35	TC
6	EH1047	Nut, Lock, Air Vent, PVDF	1	10, 15, 20	TC
	EH1092	Nut, Lock, Air Vent, PVDF	1	30, 35	TC
* 8	E90064	Diaphragm and retainer, EW/EK/EZ10	1	10	all
	E90065	Diaphragm and retainer, EW/EK/EZ15	1	15	all
	E90066	Diaphragm and retainer, EW/EK/EZ20	1	20	all
	E90067	Diaphragm and retainer, EW/EK/EZ30	1	30	all
	E90490	Diaphragm and retainer, EW/EK/EZ35	1	35	all
10	EH1052	Body, Manual Air Vent, PVDF	1	10, 15, 20	TC
	EH1100	Body, Manual Air Vent, PVDF	1	30, 35	TC
* 11	EH0340	Guide, Valve, .188 PVDF	4	10	FC
	EH1046	Guide, Valve, .188 PVDF	4	10	TC
	EH1549	Guide, Valve, .250 PVDF	4	15, 20	FC, TC
	EH1550	Guide, Valve, .375 PVDF	4	30, 35	FC, TC
* 12	EH1627	Seat, Valve, .188 PCTFE	4	10	FC
	EH0592	Seat, Valve, .250 PCTFE	4	15, 20	FC
	EH0593	Seat, Valve, .375 PCTFE	4	30, 35	FC
	EH0061	Seat, Valve, .188 FKM	4	10	TC
	EH0069	Seat, Valve, .250 FKM	4	15, 20	TC
	EH0119	Seat, Valve, .375 FKM	4	30, 35	TC
* 13	EH0025	Ball, Valve, .188 CE	4	10	FC, TC
	EH0084	Ball, Valve, .250 CE	4	15, 20	FC, TC
	EH0120	Ball, Valve, .375 CE	4	30, 35	FC, TC
* 14	EH0342	Gasket, Valve, .188 & .250 PTFE	6 / 2	10, 15, 20	FC / TC
	EH0354	Gasket, Valve, .375, PTFE	6 / 2	30, 35	FC / TC
15	EH1080	O-Ring, P-3, FKM	1	30, 35	TC
16	EH0029	O-Ring, P-6, FKM	1	30, 35	TC
* 17	EH0027	O-Ring, S-14, FKM	2	10, 15, 20	TC
	EH0122	O-Ring, P-16, FKM	2	30, 35	TC
	EH0591	Gasket, V-Housing, .188/.250 PTFE	2	10, 15, 20	FC
* 18	EH0355	Gasket, V-Housing, .375 PTFE	2	30, 35	FC
	EH0027	O-Ring, S-14, FKM	1	30, 35	TC
19	EH0403	Bolt, M4 x 33 SS Hex Socket	4	30	FC, TC
	EH1630	Bolt, M4 x 30 SS Hex Socket	4	10, 15, 20	FC, TC
	EH1347	Bolt, M5 x 35 SS Hex Socket	4	35	FC, TC
23	EH1049	Knob, Air Vent Valve	1	10, 15, 20	FC, TC
	EH1094	Knob, Air Vent, 1/2, PVDF	1	30, 35	FC, TC
* 25	EH0300	O-Ring, P-4, FKM	1	10, 15, 20	TC
* 26	EH0302	O-Ring, P-10A, FKM	1	10, 15, 20	TC
* 27	EH0304	O-Ring, P-7, FKM	1	10, 15, 20	TC
	EH1082	O-Ring, P-11, FKM	1	30, 35	TC
ZZ	-----	Brass spacers			Drive specific/Re-use when replacing diaphragm
*		Included in spare parts kit			



## Accessories (Not Shown)

Part No.	Description	Size	Liquid End Material
E90001	Valve, Injection 3/8	10, 15, 20	VC
E90002	Valve, Injection 3/8	10, 15, 20	VE, VF
E90003	Valve, Injection, 3/8	10, 15, 20	PC
E90004	Valve, Injection, 3/8	10, 15, 20	PE
E90005	Valve, Injection 1/2	EHC30	VC
E90006	Valve, Injection 1/2	EHC30	VE, VF
E90007	Valve, Injection, 1/2	EZ30/35, EHB30, EHC35	VC
E90008	Valve, Injection, 1/2	EZ30/35, EHB30, EHC35	VE, VF
E90009	Valve, Injection, 1/2	EHC30	PC
E90010	Valve, Injection, 1/2	EHC30	PE
E90011	Valve, Injection, 1/2	EZ30/35, EHB30, EHC35	PC
E90012	Valve, Injection, 1/2	EZ30/35, EHB30, EHC35	PE
E90238	Valve, Injection, 3/8	10, 15, 20	TC
E90020	Valve, Inj/Back Press, 3/8	10, 15, 20	FC
E90022	Valve, Inj/Back Press, 1/2	30, 35	TC, FC
E90013	Valve, Foot, 3/8	10, 15, 20	VC
E90015	Valve, Foot, 3/8	10, 15, 20	PC
E90016	Valve, Foot, 1/2	30, 35	VC
E90018	Valve, Foot, 1/2	30, 35	PC
E90034	Valve, Foot, 3/8	10, 15, 20	PE
E90035	Valve, Foot, 3/8	10, 15, 20	VE
E90036	Valve, Foot, 1/2	30, 35	PE
E90037	Valve, Foot, 1/2	30, 35	VE
E90193	Valve, Foot, 1/2	30, 35	VF
E90234	Valve, Foot, 3/8	10, 15, 20	VF
E90239	Valve, Foot, 1/2	30, 35	TC
E90240	Valve, Foot, 3/8	10, 15, 20	TC
E90241	Valve, Foot, 3/8	10, 15, 20	FC
E90275	Valve, Foot, 1/2	30, 35	FC
E00001-00	Tubing, 1/2 OD LLDPE per foot	30, 35	all
E00001	Tubing, 1/2 OD LLDPE, 20 FT	30, 35	all
E00001-50	Tubing, 1/2 OD LLDPE, 50 FT	30, 35	all
E00001-100	Tubing, 1/2 OD LLDPE, 100 FT	30, 35	all
E00001-250	Tubing, 1/2 OD LLDPE, 250 FT	30, 35	all
E00001-500	Tubing, 1/2 OD LLDPE, 500 FT	30, 35	all
E00002-00	Tubing, 3/8 OD LLDPE per foot	10, 15, 20	all
E00002	Tubing, 3/8 OD LLDPE, 20 FT	10, 15, 20	all
E00002-50	Tubing, 3/8 OD LLDPE, 50 FT	10, 15, 20	all
E00002-100	Tubing, 3/8 OD LLDPE, 100 FT	10, 15, 20	all
E00002-250	Tubing, 3/8 OD LLDPE, 250 FT	10, 15, 20	all
E00002-500	Tubing, 3/8 OD LLDPE, 500 FT	10, 15, 20	all
E00071	Weight, Ceramic	10,15,20,30,35	all

## 8.0 TROUBLESHOOTING

**CAUTION:** Before working on the pump, disconnect the power cord, depressurize the discharge tubing and drain or flush any residual liquid from the pump head and valves, using proper chemical handling techniques.

<u>Problem</u>	<u>Possible Cause</u>	<u>Corrective Action</u>
<i>Pump does not start</i>	Faulty wiring	Correct wiring
	Improper voltage	Connect to proper voltage source
	Electronic control unit is damaged	Replace control unit
<i>Pump does not prime</i>	Pump stroke length is too short	Operate pump with stroke length set at 100% until primed. Then set stroke length as needed to obtain desired output.
	Air in suction tubing	Reroute suction tubing to eliminate air trap
	Valve gasket is not installed	Install valve gasket
	Valve set assembly direction is wrong.	Reassemble valve set
	Pump is air locked	Open air vent valve
	Suction or discharge valve is clogged with foreign matter	Disassemble, inspect, clean
	Ball stuck to valve seat	Disassemble, inspect, clean

<b><u>Problem</u></b>	<b><u>Possible Cause</u></b>	<b><u>Corrective Action</u></b>
<b><i>Output fluctuates</i></b>	Suction or discharge valve is clogged with foreign matter	Disassemble, inspect, clean
	Air is trapped in pump	Open air vent valve
	Overfeeding	Install injection valve or back pressure valve
	Diaphragm is damaged	Replace diaphragm
<b><i>Liquid leaks</i></b>	Fitting or coupling nut is loose	Re-install (see section 2.3/2.4)
	Pump head is loose	Tighten pump head bolts Torque: 19 lb-in (2.16 N-m)
	Diaphragm is damaged	Replace diaphragm
	O-ring or valve gasket missing	Install o-ring or valve gasket

## **9.0 SERVICE POLICY**

The EW Series electronic metering pumps have a 2-year limited warranty. Contact your Walchem distributor for service.

---

**W A L C H E M**

---

Five Boynton Road Hopping Brook Park Holliston, MA 01746 USA TEL 508-429-1110 FAX 508-429-7433  
WEBSITE: [www.walchem.com](http://www.walchem.com)