




EWN-R Metering Pump Connection Diagram

EWN-R Pump



CONNECTOR 1:

P/N E90495: 5-Pin Round, Standard Key

- Pin #1: AUX Input (+)
- Pin #2: DIG Pulse Input (+)
- Pin #3: Analog Input (+)
- Pin #4: OUT 1 (SPM or STOP Output)
- Pin #5: Common (-)

CONNECTOR 2:

P/N E90496: 5-Pin Round, Reverse Key

- Pin #1: Start/Stop Input
- Pin #2: Pre-Stop Input
- Pin #3: Not Used
- Pin #4: Common
- Pin #5: Not Used

*Note: Connectors are NOT supplied with pump.