Using the Configuration Menu in the W600:

Importing and exporting the User Config file (used to export and import programming from one controller to another, or to save):

From the Main Menu:

1. Press ✖ Config

2. Press the Down arrow until you see File Utilities, and then press File Utilities
3. Press the Down arrow until you see Export User Config File
4. Plug your USB stick in the port in the front of the controller (after unscrewing the port cover):

Importing and exporting the User Config file (continued)

5. Press Export User Config File
6. Click the checkmark to confirm
7. File will export onto the USB stick.
8. Unplug the stick and either save it on your computer, or import it into another W600 controller.
9. To import, repeat the above steps, but at steps 3 and 5 press Import User Config File.