


Intuition-9 Email Report Settings


This document provides instructions on how to program the Email Report Settings so as to enable the controller to send user defined reports to recipients. Email Server options are included.

Log into the Intuition-9 controller using a computer. Go to the Config menu, then go to the Email Report Settings menu.



Intuition-9 Email Report Settings

Click on Email Addresses to add Email Recipients



WALCHEM
IWAKI America Inc.

Intuition-9 Controller
WCT9
CWT System

- Home
- Alarms
- Inputs
- Outputs
- Config
 - Global Settings
 - Security Settings
 - Ethernet Settings
 - WiFi Settings
 - Remote Communications
 - Email Report Settings
 - Display Settings

Email Report Settings

Date	Time
2021-Dec-30	08:42:35

Report #1	Report #2	Report #3
Inactive	Inactive	Inactive

Report #4	Email Addresses	From Addr
Inactive	1	controller

Send Email Test Report

Confirm


Test Report Recipients

#1 fsposato@walchem.com

Email Server

Walchem Fluent Edit

You can Add Up To 8 Email Recipients.



WALCHEM
IWAKI America Inc.

Intuition-9 Controller
WCT9
CWT System

- Home
- Alarms
- Inputs
- Outputs
- Config
- Graphs
- Notepad

Email Report Settings >> Email Addresses

Date	Time
2021-Dec-30	08:43:51

#1	#2	#3
fsposato@walchem.com		
#4	#5	#6
#7	#8	

Intuition-9 Email Report Settings

Setting up the Report Type – Click on Report #1 Inactive

The screenshot shows the 'Email Report Settings' page for the 'Intuition-9 Controller WCT9 CWT System'. The left sidebar contains navigation options: Home, Alarms, Inputs, Outputs, Config, Graphs, Notepad, Instruction Manual, Walchem Fluent, Walchem.com, and Admin Log Out. The main content area includes fields for Date (2021-Dec-30) and Time (09:28:15). Below these are four report status buttons: Report #1 (Inactive), Report #2 (Inactive), Report #3 (Inactive), and Report #4 (Inactive). The 'Report #1' button is highlighted with a red box. Other settings include 'Email Addresses' (1), 'From Addr' (controller), a 'Send Email Test Report' button with a 'Confirm' sub-button, 'Test Report Recipients' (fsposato@walchem.com), and 'Email Server' (Walchem Fluent) with an 'Edit' button.

Select Report Type

Options are **None/Alarm/Data Log/Graph/Summary**

This screenshot shows the 'Report #1' configuration page. The 'Report Type' dropdown menu is open, displaying the following options: None, Alarm, Data Log, Graph, and Summary. The 'Report Type' field and the dropdown menu are highlighted with a red box. The background shows the same settings as the previous screenshot, but with the focus on the dropdown menu.

Intuition-9 Email Report Settings

For example, select Summary as the Report Type.

The screenshot shows the 'Email Report Settings >> Report #1' page. On the left is a dark blue sidebar with the 'WALCHEM' logo and 'IWAKI America Inc.' text. Below the logo are navigation icons for Home, Alarms, Inputs, Outputs, Config, Graphs, and Notepad. The main content area has a light blue background and contains several settings sections: 'Date' (2021-Dec-30), 'Time' (09:37:16), 'Email Recipients' (a list with '#1 fsposato@walchem.com' checked), 'Report Type' (a dropdown menu set to 'Summary' with an 'Edit' button next to it, highlighted by a red box), and 'Repetition' (a dropdown menu set to 'None' with an 'Edit' button next to it).

Then select Repetition. In this example, Daily is selected.

This screenshot shows the same 'Email Report Settings >> Report #1' page, but with the 'Repetition' dropdown menu open. The 'Report Type' dropdown remains set to 'Summary'. The 'Repetition' dropdown menu is expanded, showing options: None, Hourly, Daily (highlighted in blue), Weekly, and Monthly. An 'Edit' button is visible to the right of the dropdown. The 'Date' is 2021-Dec-30 and the 'Time' is 09:40:06. The sidebar and other settings sections are identical to the previous screenshot.

Intuition-9 Email Report Settings

Make sure a Report Time is selected, and the Email Recipient(s) are checked off ✓

The screenshot displays the 'Email Report Settings' for 'Report #1'. The interface includes a sidebar with the following navigation items: Home, Alarms, Inputs, Outputs, Config, Graphs, Notepad, Instruction Manual, Walchem Fluent, and Walchem.com. The main content area is divided into several sections:

- Date:** 2021-Dec-30
- Time:** 10:52:39
- Report Time [HH:MM:SS]:** 09 : 00 : 00 (highlighted with a red box)
- Email Recipients:** #1 fsposato@walchem.com ✓ (highlighted with a red box)
- Report Type:** Summary (with an Edit button)
- Repetition:** Daily (with an Edit button)

Intuition-9 Email Report Settings

Email Server Settings:

Select the type of email server to be used: Walchem Fluent®, SMTP, ASMTTP, or TLS/SSL.

The screenshot displays the 'Email Report Settings' interface. On the left is a dark blue sidebar with the 'WALCHEM' logo and navigation links: Home, Alarms, Inputs, Outputs, Config, Graphs, Notepad, Instruction Manual, Walchem Fluent, Walchem.com, and Admin Log Out. The main content area is titled 'Email Report Settings' and includes:

- Date:** 2022-Jan-06
- Time:** 07:23:10
- Report #1, #2, #3, #4:** Each has an 'Inactive' button.
- Email Addresses:** A button labeled '1'.
- From Addr:** A text field containing 'CT5', highlighted with a red box.
- Send Email Test Report:** A 'Confirm' button.
- Test Report Recipients:** A list containing '#1 fsposato@walchem.com' with a checkmark.
- Email Server:** A dropdown menu highlighted with a red box, showing 'Walchem Fluent' selected and other options: SMTP, ASMTTP, and TLS/SSL.

The screen shot above shows Walchem Fluent has been selected as the Email Server. With this option, you can custom name the From Addr field. Only enter the portion of the address to be shown before the @ symbol. All emails will be from @ walchem-fluent.net. For example, in the above screen shot, the controller From Addr would be CT5@walchem-fluent.net.

Intuition-9 Email Report Settings

Alternately, you could select SMTP, ASMTMP, or TLS/SSL. You will need to obtain the information for the fields outlined in red below, from the email server service provider. The screen shot below shows ASMTMP was selected as the Email Server.

The screenshot displays the 'Email Report Settings' interface. On the left is a navigation menu with options like Home, Alarms, Inputs, Outputs, Config, Graphs, Notepad, Instruction Manual, Walchem Fluent, Walchem.com, and Admin Log Out. The main content area includes:

- Date:** 2022-Jan-06
- Time:** 08:32:33
- Report #1, #2, #3, #4:** Each has an 'Inactive' button.
- Email Addresses:** 1
- SMTP Server:** A text input field, highlighted in red.
- SMTP Port:** 587, highlighted in red.
- From Addr:** A text input field, highlighted in red.
- ASMTMP Username:** A text input field, highlighted in red.
- ASMTMP Password:** A text input field, highlighted in red.
- Send Email Test Report:** A button with a 'Confirm' sub-button.
- Test Report Recipients:** #1 fsposato@walchem.com
- Email Server:** A dropdown menu set to 'ASMTMP', highlighted in red, with an 'Edit' button next to it.

SMTP Server Will not appear if Email Server is Walchem Fluent. Enter the SMTP server address, either numeric or its name.

SMTP Port Will not appear if Email Server is Walchem Fluent. Walchem Fluent email requires that port 49887 is open. Enter the port to be used by email server. The default is port 25 for SMTP, port 587 for ASMTMP, and port 465 for TLS/SSL.

From Address Enter the controller's email address. If the email server selected is Walchem Fluent, only enter the portion of the address to be shown before the @ symbol. All emails will be from @ walchem-fluent.net

ASMTMP Username Enter the username required for authentication. Only appears if the email server type is ASMTMP or TLS/SSL.

ASMTMP Password Enter the password required for authentication. Only appears if the email server type is ASMTMP or TLS/SSL.

Intuition-9 Email Report Settings

Controller Name and Location:

WALCHEM
IWAKI America Inc.

Intuition-9 Controller
WCT9
CWT System

Home
Alarms
Inputs
Outputs
Config
Graphs
Notepad
Instruction Manual
Walchem Fluent
Walchem.com
Admin Log Out

Email Report Settings

Date: 2022-Jan-06
Time: 08:32:33

Report #1: Inactive
Report #2: Inactive
Report #3: Inactive
Report #4: Inactive

Email Addresses: 1
SMTP Server: [Empty]
SMTP Port: 587
From Addr: [Empty]
ASMTX Username: [Empty]
ASMTX Password: [Empty]

Send Email Test Report: Confirm

Test Report Recipients: #1 fsposato@walchem.com [X]

Email Server: ASMTX [Edit]

You can also program a customer name and a custom location into the controller as shown in the red outlined area in the screen shot above.

To do this, go to the Config menu/Global Settings.

WALCHEM
IWAKI America Inc.

Intuition-9 Controller
WCT9
CWT System

Home
Alarms
Inputs
Outputs
Config
Global Settings
Security Settings
Ethernet Settings
WiFi Settings

Global Settings

Date: 2022-Jan-06
Time: 08:50:14

Date [YYYY - Mmm - DD]: 2022 - Jan - 06
Time [HH:MM:SS]: 08 : 50 : 14
Name: WCT9
Location: CWT System
Global Units: Imperial
Temperature Units: °F
Alarm Delay [MM:SS]: 00 : 00
HVAC Modes: Enabled
Language: English [Edit]